BIMx DESKTOP VIEWER

SHORTCUTS FOR THE INTERNATIONAL KEYBOARD

GENERAL

Menu/Navigation	ESCAPE
View Direction	Mouse
Map Zoom	Mouse wheel
Quit	Z then ESCAPE

FLY MODE / WALK MODE

Fixed Altitude in Fly Mode	Right Mouse Button
Straight Perspective in Walk Mode	Right Mouse Button
Rotate the Model in Parallel View Mode	Mouse
Zoom In / Out in Parallel View Mode	Mouse Wheel
Pan the Model in Parallel View Mode	Right Mouse Button

GALLERY

Add New Camera Position	F4
Enter Clip Record Mode	SHIFT + R
Start / Stop Recording	Left Mouse Button
Exit Clip Record Mode	SHIFT + R
Playback the Current Clip	P
Playback all Clips	SHIFT + P